Professor: Dr. Rezaei

Student: Fateme Chaisar

Project title: Home Experiment.
Couple force in a Magnetic field

3rd s'emester of Bachlor's degree

Islamic Azad University

Required Material:

I two pieces of 15 cm copper wire

Vone piece of 50 cm copper wire

Vone Strong Magnet

Vone 1.5 v battery

VTape

Procedure:

- 1. Take one 15 cm copper wire and bend one end into an S-shape, Do the same with the other 15 cm wire; Then use these two pieces to creat a simple Stand.
- 2. Take the 50 cm copper wire and make nine turns to form a coil. fix the two ends of the coil on the stand so that it can rotate freely.

- 3. connect the free ends of the stand to the 1.5 v battery, Make sure the contact points are clean and firmly attached.
- 4. place the strong magnet near the wire coil so that the magnetic field passes trough it.
- 5. when the electric current flows through the wire, two equal and opposite forces appear on the two sides of the Coop.
- 6. These two forces form a couple, producing a net torque that causes the Loop to rotate.

Explanation:

This experiment demonstrates that a current carrying conductor in a magnetic field experiences a force. when two forces of equal magnetide act in opposite directions along different lines of action, they creat a couple, resulting intotational motion.

The characteristic of a couple force are as follows, which we were able to observe in this experiment:


I the two forces are equal in magnitude.

I the two forces act in opposite directions.

The lines of action of the two forces are parallel but not coincident.

000000000

calculation of the net torque in the constructed structure:



Befor calculating the net torque, the following steps must be followed:

Determine the total length of the wire by direct measurement:

15+15+50 = 80 cm

[2] calculating the baffery voltage by directly reading the information on the baffery:

[3] measuring the diameter of the copper wire using a ruler or more specialized tools:

-> o/l mm

14) Determine the number of turns:

-> 9 turns

[5] measure the loop radius and calculate the area:

$$t = 0.5 \text{ cm}$$
 , $A = t^{r} \Pi$, $A = (0.5 \times 1.2)^{2} \cdot 3.14$

[6] Determine the magnetic field strength by using the magnet's specifications or using a gauss meter sensor:

[7] Find the angle between the loops normal and the magnetic field direction:

$$\rightarrow \propto -90^{\circ}$$

18 calculate the resistance of the wire:

$$P = 1.68 \times 1.8 \Omega.m$$
 $R = P \frac{L}{A}$
 $L = 8 \times 1.68 \times 1.8 \times \frac{0.8}{3.14 \times 1.6} \times \frac{0.8}{3.14 \times 1.6}$
 $A = R = 1.68 \times 1.8 \times \frac{0.8}{3.14 \times 1.6}$
 $R = 4.3 \times 1.8 \Omega$

[9] Find the current passing through the wire:

$$V = 1.5 v$$
 $Z = \frac{v}{R}$

$$R = 4.3 \times 10^{-3} \Omega$$

$$I = \frac{1.5}{4.3} \times 10^{-3}$$

I = 3.5 x1.2 A

Mod calculating the magnetic moment for a coil with N turns:

$$N = 9$$
 $J = 3.5 \times 1.0 A$
 $A = 9 \times 3.5 \times 1.0 \times 8 \times 1.0 \times 1.$

M= 2.5 x1. A.m2

ce Approximate values and estimations were used in the measurements and calculations,

Ganjinek

Subject .

"Calculation of net torque"

The net torque can be calculated as follows:

 $T = F \times d$

T = Fd sin x

F=NILB sin A

T = NILB sind sina d

d = 2r $x = 90^{\circ}$ $\theta = 90^{\circ}$ L = 2r

T = NI 2r B sin(90) sin(90) 2r

T-NI 2r 2r B

 $4r^2 \sim A$

T=NIAB

According to the following formula, the torque increases with the increase of the following factors:

T = NIAB Sind

Inumber of turns

1 current

0

0

0

0

I radius of the loop

Imagnetic field

factors that may cause the experiment to

- 1) low current due a weak battery
- Dweak magnetic field caused by a low-strength magnet, It is recommended to use a neodymium magnet for this experiment

- 3) poor conductivity of the wire, It is recommended to use a copper wire for this experiment.
- At the zero Position of this experiment,
 the loop should not be perpendicular to the
 direction of the magnetic field,
 because in this case the normal vector of
 the loop makes a zero degree angle with
 the magnetic field vector,
 making sino = 0, and therefore no
 torque is produced.

[oct 2025]